



SPREADERS 12-27 IN TK-12 are suitable for vehicles with a wider container (2550 mm). The spreader is connected to the towing hook at the back of the vehicle. With chains attached to the back side of the container, it allows turning and driving in reverse. The spreading amount is set mechanically. Spreading is activated/deactivated by a button on the spreader (12/24 V) or in the vehicle cabin (additional equipment). These spreaders are best suited for spreading over traffic routes and parking areas.

Standard equipment:

- Integrated container with a volume of 1250 l
- Mechanical spreader activation with a lever on the spreader
- Spreading with a cylinder
- Epoke dosing system
- Agitator shaft
- Mesh guard (Fe) – hot-dip galvanised
- Light signalisation
- RAL 2011 colour

Additional equipment:

- Spreader activation system from the vehicle cabin
- Hook extension (tractor or truck)



Regulator for the amount of spreading material



Lever for activation/deactivation of spreader



Agitator shaft



Light signalisation



Adjustable rubber curtain



Reflective sticker



Mesh guard



Towing hook



Spreader drive

Spreader	Unit	VP 12-27	TK-12
Container volume	l	1250	1250
Spreader width	mm	2700	2500
Height of front side	mm	700	700
Spreading width	mm	2200	2200
Mass	kg	cca. 640	cca. 630
Distance of spreading with one filling: - rough material (up to 5 mm) - salt and similar material	km	5-7 15-25	5-7 15-25

